



Installing RIMMs (Rambus® inline memory modules)

- If you are installing in paired slots, compare the label on your existing RIMM to the label on your new RIMM—both RIMMs must be identical in speed, density, ECC support, and configuration.
- ALL memory slots must be full—either a RIMM (memory module) or a CRIMM (continuity RIMM placeholder) must be installed in each slot.

WARNING! RIMMs run hot enough to burn your fingertips. Use caution when removing any RIMMs that are already installed in your system.